



CONTROLLER MENU GUIDE (Continued)

- Press **Up** or **Down** key to toggle between Celsius /Fahrenheit and Languages.
- Press **X** and **Checkmark** keys at same time to save new setting and return to Misc. Functions Menu.
- Press **X** key to return to Misc. Functions Menu without saving new setting.

- Press **Checkmark** key to move cursor.
- Press **Up** or **Down** key to scroll value.
- Press **Checkmark** and **X** keys at same time to save new settings and return to Misc. Functions Menu.
- Press **X** key to return to Misc. Functions Menu without saving new settings.

- Press **Checkmark** and **X** keys at same time to save new settings and return to Configuration Menu.
- Press **X** key to return to Misc. Functions Menu without saving new settings.

- Press **Up** or **Down** key to scroll value.
- Press **Checkmark** and **X** keys at same time to save new settings and return to Misc. Functions Menu.
- Press **X** key to return to Configuration Menu without saving new settings.

- Press **Up** or **Down** key to scroll value.
- Press **Checkmark** and **X** keys at same time to save new settings and return to Configuration Menu.
- Press **X** key to return to Configuration Menu without saving new settings.

- Press **Up** or **Down** key to scroll value.
- Press **Checkmark** and **X** keys at same time to save new settings and return to Configuration Menu.
- Press **X** key to return to Configuration Menu without saving new settings.

- Press **Up** or **Down** key to scroll value.
- Press **Checkmark** and **X** keys at same time to save new settings and return to Configuration Menu.
- Press **X** key to return to Configuration Menu without saving new settings.